

Programming Remote to TV

Potenza ST

Programming Remote to Operate your TV

1. Turn on the TV.
2. Press and hold the **Setup** button until the TV button blinks twice.
3. Press the **TV** button. It will stay lit.
4. Press and hold the number related to your TV brand while pointing the remote at the device. Popular TV brand numbers:

Insignia 1

LG 2

Panasonic 3

Philips/Magnavox 4

Samsung 5

Sanyo 6

Sharp 7

Sony 8

Vizio 9

Westinghouse 0

5. Release the button when your TV turns off.

Nuvera 

844.354.4111

nuvera.net