

Programming Remote to TV

URC 2025

Linking the STB to the Remote

1. Press the **STB** button.
2. Press and hold these buttons at the same time until LED blinks twice.

Setup + A for a Cisco box

Setup + B for a Motorola or Arris box

Programming Remote to Operate your TV

1. Turn on the TV.
2. Press the **TV Mode** button.
3. Press and hold the **Setup** button until the TV mode button blinks twice.
4. Press the **TV Mode** button. It will stay lit.
5. Press and hold the **OK/Select** button, or the number related to your TV brand, until your TV turns off. Popular TV brand numbers:

Insignia/Dynex	1
LG/Zenith	2
Mitsubishi	3
Panasonic	4
Phillips/Magnavox	5
Samsung	6
Sharp	7
Sony	8
Toshiba	9
Vizio	0

6. Press the **STB** button last to control the STB.



1.844.354.4111

nuvera.net

Programming Remote to TV

URC 2025

Linking the STB to the Remote

1. Press the **STB** button.
2. Press and hold these buttons at the same time until LED blinks twice.

Setup + A for a Cisco box

Setup + B for a Motorola or Arris box

Programming Remote to Operate your TV

1. Turn on the TV.
2. Press the **TV Mode** button.
3. Press and hold the **Setup** button until the TV mode button blinks twice.
4. Press the **TV Mode** button. It will stay lit.
5. Press and hold the **OK/Select** button, or the number related to your TV brand, until your TV turns off. Popular TV brand numbers:

Insignia/Dynex	1
LG/Zenith	2
Mitsubishi	3
Panasonic	4
Phillips/Magnavox	5
Samsung	6
Sharp	7
Sony	8
Toshiba	9
Vizio	0

6. Press the **STB** button last to control the STB.



1.844.354.4111

nuvera.net

Programming Remote to TV

URC 2025

Linking the STB to the Remote

1. Press the **STB** button.
2. Press and hold these buttons at the same time until LED blinks twice.

Setup + A for a Cisco box

Setup + B for a Motorola or Arris box

Programming Remote to Operate your TV

1. Turn on the TV.
2. Press the **TV Mode** button.
3. Press and hold the **Setup** button until the TV mode button blinks twice.
4. Press the **TV Mode** button. It will stay lit.
5. Press and hold the **OK/Select** button, or the number related to your TV brand, until your TV turns off. Popular TV brand numbers:

Insignia/Dynex	1
LG/Zenith	2
Mitsubishi	3
Panasonic	4
Phillips/Magnavox	5
Samsung	6
Sharp	7
Sony	8
Toshiba	9
Vizio	0

6. Press the **STB** button last to control the STB.



1.844.354.4111

nuvera.net