



Potenza Remote Television Setup Codes

Acer	1339	Contec	0180
Admiral	0093, 0463	Craig	0180, 3423
Advent	1570	Crosley	0054, 0000
Affinity	3716, 3717	Crown	0180
Aiko	0092	Curtis	2397, 3577, 2352, 2466, 2855, 3228, 1326
Aiwa	1362	Curtis Mathes	0702, 0054, 0093, 0060, 0047, 0154, 0451, 0145, 1661, 0056, 1347, 1959
Akai	0812, 0702, 1675, 0765, 1385	CXC	0180
America Action	0180	Cytron	1326
Anam	0180	Daewoo	1661, 0661, 0092, 0154, 0451
AOC	1589, 2087, 1365, 1590, 2014, 2479, 3707, 3720	Dell	1264, 1080, 1863, 2491
Aomni	1623	Denon	0145
Apex Digital	2397, 0748, 0879, 0765, 1217	Digital Lifestyles	1765
Astar	1548, 1738	Disney	1665, 1892
Asus	3340	Dumont	0017
Audiovox	1564, 0451, 0180, 0092, 1276, 1766, 1769, 1865, 1868, 2121, 2413, 3065	Durabrand	0178, 0171, 0463, 0180, 1665
Auria	2087, 2277	Dynex	2049, 1463, 1785, 1810, 2184
Aventura	0171	Electric Mirror	3166
Bell & Howell	0154	Electroband	0000
Berkshire	0047	Electrograph	1755, 1623
Bradford	0180	Electrohome	0463, 1570, 1670
Broksonic	0463, 1938	Element	1886, 1687, 2183, 2964, 3559
Candle	0056	Elite	1457
Carver	0054	Emerson	1864, 1394, 1886, 0171, 0178, 0154, 0451, 0463, 0180, 1661, 1665, 1913, 1944, 1963, 2183, 2776, 3559
Celebrity	0000	Emprex	1765
Celera	0765	Envision	1589, 2087, 1365, 2014
Champion	1362	Epson	1122
Changhong	0765	ESA	0812, 0171, 1944, 1963
Citizen	0060, 0092, 0056	Fisher	0154, 1362
Clarion	0180	Fluid	2964
Coby	3478, 3627, 2315, 2344, 2306, 2314, 2326, 2338, 2340, 2345, 2347, 2348, 2560, 3629, 1538	Fujitsu	0809
Commercial Solutions	1447, 0047	Funai	0000, 0171, 0180, 1271, 1904, 1963
Concerto	0056		

Futuretech.....	0180	Konka.....	1385, 1831
Gateway.....	1756, 1755	KTV.....	0180
GE.....	1447, 0178, 0047, 0051, 0451, 0765, 1347, 1547	Lasonic.....	3198
GFM.....	1864, 1886, 0171, 1665, 1963	LG.....	1423, 2731, 2358, 2424, 0178, 3397, 1265, 2834, 3098, 2612, 0017
Gibraltar.....	0017	Lloyd's.....	1904
Go Video.....	1823, 1831	LodgingStar.....	3147
GoldStar.....	0178, 0056	Luxman.....	0056
GPX.....	3196	LXI.....	0156, 0054, 0178, 0047, 0154
Grunpy.....	0180	MAG.....	1498, 1687
Haier.....	1753, 1749, 2309, 1748, 3382, 1570, 2293	Magnasonic.....	1913
Hallmark.....	0178	Magnavox.....	1867, 1454, 1455, 2597, 2372, 1866, 0054, 0171, 0706, 1365, 1904, 1913, 1944, 1963, 1990, 2902, 3708, 1755, 0051
Hannspree.....	1348, 1351, 2786	Marantz.....	1454, 0054, 1398
Harley Davidson.....	1904	Matsushita.....	0250, 0650
Harman/Kardon.....	0054	Maxent.....	1755, 1757
Harvard.....	0180	MB Quart.....	1868
Havermy.....	0093	Megatron.....	0178, 0145
Hello Kitty.....	0451, 2776	Memorex.....	0463, 0178, 0154, 0150, 1570, 1665, 1670, 1785, 1892, 1924, 1927, 1938
Hewlett Packard.....	1642	MGA.....	0178, 0150
Hisense.....	3519, 2183, 0748, 1314, 1660, 2098	Midland.....	0047, 0017, 0051
Hitachi.....	1643, 0145, 1145, 0056, 0679, 1576, 1904, 2756	Mintek.....	1990
iLo.....	1394, 1463, 1286, 1665, 1684, 1990	Mitsubishi.....	1250, 0150, 1797, 0093, 0178
Infinity.....	0054	Motorola.....	0093
Initial.....	1990	MTC.....	0060, 0056
Insignia.....	2049, 1641, 1326, 1564, 1423, 2002, 1785, 1892, 2184, 2417, 2751, 0171, 0463, 2088, 1963, 1660, 1517, 1385	Multitech.....	0180
Inteq.....	0017	NAD.....	0156, 1156, 0178, 0056
iSymphony.....	3094, 3118, 3382	Naxa.....	2104, 3154, 3382
JBL.....	0054	NEC.....	0056, 1398, 1704, 1797, 2293
JCB.....	0000	NetTV.....	1755
JCM.....	2256	Nexus Electronics.....	2183
Jensen.....	1326, 2541	Nikko.....	0178, 0092
JVC.....	1774, 1601, 2271, 2264, 0053, 0650, 0463, 0731, 1253, 1670, 1923, 2321	Norcent.....	1589, 0748, 1365, 1590
KDS.....	1498, 1687	Norwood Micro.....	1286
KEC.....	0180	NTC.....	0092
KLH.....	0765		

NuVision.....	1657, 2158	Sanyo	1142, 0154, 1362, 0054, 0088
Ölevia.....	1610, 1144, 1240	Sceptre.....	0878, 1217, 1360, 1599, 2337, 2506, 2528
Onwa.....	0180	Scotch.....	0178
Optimus.....	0250, 0650, 0154, 1913, 1924, 1927	Scott.....	0178, 0180
Optoma.....	1348	Sears.....	0156, 0054, 0178, 0047, 0171, 0154, 0056, 1904
Optonica.....	0093	Seiki.....	0178, 2964, 3559, 3560
Orion.....	0463, 1463, 1938, 3540	Seleco.....	1351
Panasonic.....	1480, 1291, 0250, 0650, 2264, 1927, 1924, 1947, 0051, 1941, 1310, 1271, 1946	Sens.....	1865
PARK.....	2104	Sharp.....	2360, 0818, 0093
Penney.....	0156, 0178, 0060, 0047, 0051, 1347	Sheng Chia.....	0093
Philco.....	1394, 0054, 0171, 1271, 1665, 1963	Sherwood.....	1399, 3061
Philips.....	1454, 1867, 2372, 1744, 1455, 2374, 2597, 1866, 0690, 0054, 2704, 1394, 0171, 1365, 1944, 1990, 2902	Sigmac.....	3423, 3477
Pioneer.....	1457, 0679, 1260, 1398	Signature.....	0054
Planar.....	1589	Solé.....	1623
Polaroid.....	1523, 1498, 0765, 1276, 1286, 1314, 1326, 1385, 1538, 1687, 1766, 1767, 1769, 2002, 2121	Sony.....	0810, 0000, 1300, 0834, 1685, 1904
Portland.....	0451, 0092, 1661	Soundesign.....	0178, 0180
Prima.....	1753, 1749, 1785	Soyo.....	1831
Prism.....	0051	Spectroniq.....	1498, 1687
Proscan.....	1447, 0047, 1347, 2147, 2183, 2256, 3577	Squareview.....	0171
Proton.....	0178	SSS.....	0180
Proview.....	1498, 1687	Starlite.....	0180
Pulsar.....	0017	SunBriteTV.....	1610, 2337, 2528, 2935
Quasar.....	0250, 1291, 0650, 0051, 1924, 1927	Superscan.....	0864, 0093, 1944
RadioShack.....	0178, 0047, 0154, 0180, 0056, 1904	Supersonic.....	1753, 2104, 3154, 3593
RCA.....	1447, 2746, 2434, 2932, 2247, 2187, 0047, 1781, 0093, 3577, 3147, 2855, 2002, 1959, 1547, 1385, 1347, 0679, 0051, 1661, 0090	Supreme.....	0000
Realistic.....	0178, 0154, 0180, 0056	SVA.....	0748, 1963
RevolutionHD.....	1623	Sylvania.....	1864, 1394, 1886, 0171, 1944, 1963, 1271, 0054, 1314, 1665, 1913, 3563
Runco.....	0017, 1398	Symphonic.....	1394, 0171, 0180, 1904, 1913, 1944
Sampo.....	1755	Syntax.....	1610, 1144, 1240
Samsung.....	2051, 0812, 0702, 0060, 1060, 0766, 0814, 1959, 2596, 0650, 0178, 0056	Tandy.....	0093
Sansui.....	0171, 0463, 1463, 1670, 1892, 1904, 1938, 3540, 3564	Tatung.....	1756, 1286
		TCL.....	2434, 3183
		Technics.....	0250, 0051
		Techwood.....	0051, 0056
		Teknika.....	0054, 0060, 0180, 0150, 0092, 0056

Telefunken.....0702, 0056
Thomas America1904
TMK0178, 0056
TNCi.....0017
Toshiba..... 1524, 1656, 2724, 0156, 1156, 0822, 1256,
2006, 0060, 0154, 1265, 2684, 1959, 1945,
1704, 0650, 1369
TruTech 1665, 1723, 2066
TVS.....0463
US Logic1286
Venturer 1865, 1868
Victor.....0053
Vidikron0054, 1398
Vidtech0178
Viewsonic..... 2087, 2014, 2049, 0864, 1755,
1564, 0885, 1330, 1365,
1542, 1578, 1627, 2277, 3706
Viore.....1684, 2104, 2352, 3094, 3118, 3382
VisionQuest.....3380
Vivitek.....1369
VIZIO1758, 3758, 2757, 3358, 2512, 1756, 0864, 0885
Wards 0156, 1156, 0054, 0000, 0178, 0060, 0047,
0154, 0017, 0051, 0180, 0056, 1347
Waycon.....0156
Westinghouse.....1712, 3579, 0885, 3382, 1300, 1577,
3094, 3470, 0889, 1282, 2293, 0451, 1217
White Westinghouse.....0463, 1661
Wyse.....1365
Zenith 1423, 0017, 2358, 2731, 0000, 0178, 0047,
0463, 1265, 1145, 0145, 0092, 1661, 1365,
1904, 2612